


The Load "Curves"

The curves trace upward from the horizontal position.

These lines show how high and far the load may be lifted.

This diagram is important to determine how the crane will perform above the horizontal position.



BIGMAX[®]
BY TECHNOCRANE