


Reading a Basic Load Diagram



- This simple load diagram shows the lift capacity (kg) of the crane at various distances (m).
- Note how the lift capacity and distance are related; the capacity decreases as the distance increases
- Adding certain accessories like grabs or winches may change the size of the crane you need

BIGMAX[®]
BY TECHNOCRANE